

How to ENABLE/DISABLE physical SIM 2? (For 9x30 and 9x50 families)

a. Open AT command port (Please refer to [Slide 2](#))

b. Send the commands below:

```
//Disable physical SIM 2
```

```
AT!ENTERCND="A710"
```

```
AT!CUSTOM="UIM2ENABLE",0
```

```
AT!RESET
```

```
//Enable physical SIM 2
```

```
AT!ENTERCND="A710"
```

```
AT!CUSTOM="UIM2ENABLE",1
```

```
AT!RESET
```

How to use AT command for SDX55 chipset on Windows (EM91 Series/EM7690)?

- For MBPW Release 31 or newer, please add “**EnableUDE=1**” in configuration.ini, then install the driver.
- Open Device Manager and find **Modem Port**
- Right click -> properties -> Modem -> Port: COMx
- The example is COM13

